



OVERSHOES & DISPENSER

Easy-to-use overshoe dispenser, ideal to EPA or clean-room visitors. The dispenser is delivered without overshoes. The overshoes are specifically designed for this dispenser.

Overshoe specifications :

Material :	Fabric with a conductive ribbon
Weight :	40 g/m ²
Colour :	Yellow
Size :	Fits to all sizes between 35 & 48
Resistance to ground :	10e5 Ω
Usage precautions :	Do not wash, do not put in contact with detergents.
Packaging :	200 pairs / bag

Partnumbers :

Dispenser :	30-551-5000
Overshoes :	30-551-5001

How to fill in the dispenser :

- 1- Open the box
- 2- Push the side rails up to the click
- 3- Bind the 10-packed overshoes to the rings at each angle (up to 5 packs)
- 4- Unclick the side rails by pushing them
- 5- Close the dispenser which is now ready to use

How to use the dispenser :



- Put one foot after the other in the dispenser and push the pedal to the end.
- The overshoe is then automatically put around the shoe
- The conductive ribbon should be manually adjusted into the shoe.



SURCHAUSSES & DISTRIBUTEUR

Distributeur de surchausses facile d'utilisation, idéal pour les visiteurs d'EPA ou de salles blanches. Le distributeur est livré vide. Les surchausses sont spécifiquement conçues pour ce distributeur.

Spécification des surchausses :

Matière :	Tissus avec ruban conducteur
Poids :	40 g/m ²
Couleur :	Jaune
Taille :	Convient à toutes les tailles du 35 au 48
Résistance à la terre :	10e5 Ω
Précautions d'usage :	Ne pas laver, ne pas mettre en contact avec un détergent.
Conditionnement :	200 paires / sachet

Références :

Distributeur :	30-551-5000
Surchausses :	30-551-5001

Comment remplir le distributeur :

- 1- Ouvrir la boîte
- 2- Pousser les 2 rails latéraux vers le bas jusqu'au clic
- 3- Relier chaque paquet de 10 surchausses aux 4 œillets dans les angles
- 4- Déverrouiller les rails latéraux en poussant vers le bas
- 5- Fermer le distributeur. Celui-ci est alors prêt à fonctionner.

Comment utiliser le distributeur :



- Poser un pied après l'autre dans l'appareil et pousser la pédale jusqu'à la butée.
- La surchausse est alors positionnée automatiquement autour de la chaussure
- La bande de contact doit être positionnée à la main à l'intérieur de la chaussure